SORAA

AIA Provider Number: 40107394

TM-30: The Science of Color Accuracy

Course Number: SOR30

Credit(s) earned on completion of this course will be reported to AIA CES for AIA members. Certificates of Completion for both AIA members and non-AIA members are available upon request. This course is registered with AIA CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.

Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.

Course Description/Overview

When we see an object illuminated by a light source, we see a color. This color corresponds to a point in color space. Colors are characterized by their **hue** (red/yellow/green/blue) and by their **saturation** (from dull to very saturated).

The CRI is the standard for color rendition, but suffers from issues such as inaccuracy—due to outdated color science and a lack of information (only one number to characterize color).

To address these issues, the IES formed a task group which created TM-30. SORAA's scientists led the technical work of TM-30. TM-30 uses state-of-the-art color science and produces more information with higher accuracy about color rendition

TM-30, together with other color quality metrics, is used to design optimal products.

Learning Objectives

At the end of this course, participants will be able to:

- 1. Understand the importance of TM-30 and how it is used to understand color accuracy
- 2. Understand how to evaluate color quality in LED lamps beyond CRI
- 3. Understand how TM-30 evaluates color rendition with better science than the CRI did
- Learn how to identify Rf and Rfh1, for highfidelity sources, Rg and red saturation, for colorenhancing sources, the whiteness index Rw and chromaticity



Introduction



The CRI is the standard for color rendition, but suffers from issues:


- Inaccuracy—due to outdated color science
- Lack of information (only one number to characterize color)

To address these issues, the IES formed a task group which created TM-30. SORAA's scientists led the technical work of TM-30.


TM-30 uses state-of-the-art color science and produces more information with higher accuracy about color rendition.


SORAA uses TM-30, together with other color quality metrics, to design optimal products.

Many ways to describe a light source:



Many ways to describe a light source:






When we see an object illuminated by a light source, we see a color.

This color corresponds to a point in color space.

Colors are characterized by:

• their hue (red/yellow/green/blue)




When we see an object illuminated by a light source, we see a color.

This color corresponds to a point in color space.


Colors are characterized by:


- their hue (red/yellow/green/blue)
- their saturation (from dull to very saturated).



Each color corresponds to a point in color space, and is characterized by its hue and saturation

"Natural color" of an object = its color under natural light (sunlight / incandescent, depending on the CCT)





 Artificial light sources can distort colors from their natural appearance

 In general, a light source can modify the hue and/or saturation of objects


Corresponding Appearance

TM-30 color icon

If we take a series of colored samples and compute their color distortions under a light source, we get a "map" of how various colors are distorted.

In this example, we have a light source for which:

- red is de-saturated (more dull)
- orange is shifted toward yellow
- cyan is shifted towards blue




TM-30 color icon

This is precisely how TM-30 works. TM-30 has 99 carefully-chosen color samples. Each arrow is obtained from averaging several samples of similar color.

This diagram is called the TM-30 color icon.


It tells us a lot of information about the color rendition of a light source.



This light source hardly causes any color distortion: all the arrows are very small.


It is a (nearly-ideal) halogen lamp.

"Color fidelity" = the fact of rendering colors naturally. This is a high-fidelity source.




This light source has small color distortion for blue colors, and no color distortion for red colors

It is a **high-fidelity LED** (with high-CRI and high R9)




This light source has color distortion for all colors. It makes red and warm colors less saturated.

It is a low-fidelity LED (low CRI, low R9).



This light source also has color distortion for all colors. However, it makes red and warm colors more saturated.

It is a "color-enhancing" LED




TM-30 Rf

From the icon, TM-30 derives Rf (color fidelity index)

Rf describes the average color distortion. It is calculated from the average length of the arrows.

- Rf = 100 happens when all the arrows have zero length, i.e. when all the colors are identical to natural colors (Example: halogen lamp)
- Rf decreases when colors become different from natural colors (longer arrows on the icon)
- Rf gives similar information to the CRI, but is more accurate
- There is also a metric for red: Rfh1 (which replaces R9)




Longer arrows = lower Rf

TM-30 Rg

From the icon, TM-30 derives Rg (color gamut index)

Rg describes the increase/decrease in color saturation. It is calculated by connecting the tips of the arrows, and looking at the area of the resulting shape.

- Rg = 100 happens when on average colors are neither over- nor undersaturated
- Rg > 100 happens when, on average, colors are saturated (more vivid)
- Rg < 100 happens when, on average, colors are de-saturated (more dull)



Larger dotted shape = higher Rg



Understanding TM-30 Data

- The color icon tells us what happens to specific colors
- Rf tells us if colors are "natural", i.e. similar to natural colors (Rf = 100 is the maximum)
- Rg tells us if colors are natural (Rg = 100), saturated (Rg > 100), de-saturated (Rg < 100)
- There is also a "red fidelity index" called Rfh1, which replaces R9

Three Important Classes of Products

1. High-fidelity sources (a.k.a. "high-CRI")


- Render colors like natural light
- Rf and Rg close to 100
- Useful in a variety of situations where natural colors are sought

2. High-saturation sources ("Color-enhancing")

- Increase the vividness of colors
- Have lower Rf, but high Rg (e.g. Rg=110-120)
- Useful in some cases to make colors "pop"


3. Low-saturation sources (most "low-CRI" LEDs)

- Makes colors dull and is usually less liked
- Have higher lumens/watts
- Have low Rf and low Rg




Depending on the application, high-fidelity sources or high-gamut sources can be preferable.

Why the CRI is not enough: The difference between fidelity and saturation




Low saturation source
Dull colors
CRI = 80, R9 = 0



Natural colors

CRI = 95, R9 = 95



High saturation source Saturated colors CRI = 80, R9 = 0


Very often, sources with low R9 have low red saturation (this is bad)
However, color-enhancing sources *also* have low R9 (saturated reds are not accurate, but may be pleasant)

Reading the information of TM-30 - examples

Rf = 78 — This source does not render colors accurately

Rg = 111 ————— It tends to over-saturate colors

Color-enhancing source




Specifically, it saturates warm colors (red, orange, pink, skin tones)

...and also green colors (plants and leaves...)

Important note: for "color-enhancing sources", users should check what colors are enhanced. Very often, warm colors are what matters most.

Reading the information of TM-30 - examples


Another color-enhancing source...



However, this source only saturates yellows

...might be useful in a very specific application, but probably not great in general

How do we calculate TM-30 in practice?



All you need to compute TM-30 values is:


The SPD you are interested in (from a manufacturer spreadsheet, or a hand-held spectrometer)

The IES TM-30 spreadsheet (comes with the TM-30 document, sold by the IES)

The TM-30 spreadsheet: reading results

In addition to Rf, Rg and the color icon, TM-30 displays a variety of results:

The Rf-Rg graph shows both Rf and Rg and illustrates the trade-off between the two: high values of Rf constrict Rg to a specific range



The gray line shows the maximum / minimum possible value of Rg for a given Rf


In this example, the light source has a low fidelity index and a slightly low gamut index

The TM-30 spreadsheet: reading results

In addition to Rf, Rg and the color icon, TM-30 displays a variety of results:

The fidelity bar chart shows the fidelity index for all 16 bins.

Rf is (approximately) the average of these 16 values.




In this example, some greens and blues are accurately rendered, but reds are very distorted

The TM-30 spreadsheet: reading results

In addition to Rf, Rg and the color icon, TM-30 displays a variety of results:


The saturation bar chart shows the change in chroma (i.e. in saturation) for all 16 bins.




In this example, some reds and greens are desaturated, whereas yellows and blues are over-saturated

Remember - TM-30 is only part of the story

For instance, not all high-fidelity sources are equal...



RW = 0 (whiteness index, not part of TM-30!)
No rendering of white objects



 $Rf = 93 \\ Rw = 100 \\ Accurate rendering of colors and whites$

Light sources can modify color in various ways: hue shift and saturation change.

TM-30 evaluates color rendition with better science than the CRI did.

Summary

It generates a variety of information: Rf (and Rfh1), Rg, color icon. These give advanced user more insight in the color rendition of a source.

Summary

Remember: TM-30 tells you about object colors, which is **only one aspect** of the quality of light. To fully evaluate a light source, users should look at:

- CCT + chromaticity (for the color of the light itself)
- TM30 Rf and Rfh1 (for high-fidelity sources)
- TM30 Rg (for color-enhancing sources)
- TM30 icon (to know about specific colors)
- Whiteness index Rw (for whites rendering)